



Grid-connected PV Inverter

SUN-6K-G06-LV-P1

User Manual



